

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 1 of 33



Content

1	Changelog	2
2	Cleaning and Handling of Sensors with Optical Elements	3
3	Principal Schematic for HTPA120x84d	5
4	Pin Assignment – Bottom View	6
5	Optical Orientation.....	7
6	Order Code Example.....	8
7	Application note.....	9
8	Serial Order of Frame	10
9	Characteristics.....	11
9.1	Common Specifications.....	11
9.2	Filter characteristics.....	11
10	Electric Specifications.....	12
11	SPI Timings HTPA120x84d	14
12	SPI Communication	15
12.1	Write Command.....	15
12.2	Read Command.....	15
12.3	Sensor Commands	16
12.4	EEPROM communication	19
12.5	SPI Example Sequences – Init and Read Thermopile Array	20
13	Temperature calculation	21
13.1	Ambient Temperature	23
13.2	Thermal Offset	23
13.3	Electrical Offset	24
13.4	Vdd Compensation.....	24
13.5	Object Temperature	26
14	Example calculation	27
14.1	Pixel Masking	29
14.2	Look-up Table.....	32
15	Outer Dimension	33

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 2 of 33



1 Changelog

2021-01-30	Revised order code; Added change notes; revised TRIM registers
2021-08-12	New order code; Added formula for pixel masking; Correction pixel size
2021-08-16	Added datasheet for L3.9/L4.8
2021-09-20	Corrected EEPROM map
2021-10-29	Deleted PU (not necessary), updated EEPROM-map, corrected absorbersize, delete address (sensor commands)
2022-01-26	Updated EEPROM Map
2022-04-21	Small corrections in exemplary calculations, corrected graph for SPI Timings
2022-08-01	Added L21.5 and L33 variant
2023-11-14	Note on the use of the SPI pin added
2024-12-12	Renamed Sensors with L0 to Laser Beam Profiler

2 Cleaning and Handling of Sensors with Optical Elements

Cleaning of Filter with Isopropyl Alcohol or Acetone

This is the method most universally used for cleaning optical elements with or without coatings. Filters or lenses mounted in our sensors may be cleaned rubbing the surfaces lightly with a clean, soft, all-cotton cloth or cotton swab during immersion in solvent or simply moistened with the solvent. The parts are then immediately wiped dry with another clean, soft, all-cotton cloth or cotton swab.

Cleaning with Detergent and Water

A very mild, non-abrasive detergent (one which does not contain additives) and water may also be used for cleaning optical elements. In general, a detergent and water mixture is an excellent method for removing fingerprints and other smudges. The liquid detergent is first mixed with deionized water (proportions recommended by the manufacturer should be followed). The element is then washed, rinsed, and immediately wiped dry. Use a clean, soft cloth when cleaning and drying. If the part is allowed to dry in air, a permanent stain may result.

Please note:

- Do not use isopropyl alcohol or acetone or detergent if the elements will be mounted in an assembly with a finish which may be soluble by these solvents.
- Please avoid glass isolation being moistened by solvent.
- If the part is allowed to dry in air, a permanent stain may result.

Handling Advises

Sensors with optical elements deserve special consideration in their handling and care. Ordinarily, filters or lenses are cleaned and inspected prior to shipment. If proper care is exercised during handling cleaning should not be necessary prior to use.

- Wear gloves when handling a sensor or optical element. Lightweight nylon or cotton gloves which are relatively lint-free are recommended.
- Avoid touching the surface of filters and lenses.
- Protect devices from static discharge and static fields.
- Thermopile sensors are electrostatic sensitive devices. Sensors should be handled over an electrostatic protected work area.
- Precautions should be taken to avoid reverse polarity of power supply for sensors with integrated signal processing. Reversed polarity of power supply results in a destroyed unit.
- Sensors should rest preferably in a partitioned container where the mounted filters or lenses will be not coming into contact with other material.
- During storage optical surfaces should be covered to avoid contamination from the surrounding environment.
- A covered container can eliminate damage during transportation and storage.

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 4 of 33



- Sensors or optical elements should be stored in a restricted access area to eliminate handling
- Do not expose the sensors to aggressive detergents such as freon, trichlorethylen, etc.
- Avoid rotating the sensors when they are soldered into a PCB or something similar
- Shortening of the pins is not suggested. This may cause cracks in the glass of the pins and result in a leakage.
- If this is necessary, a tool for this is recommended. Please contact Heimann Sensor for further information.

Soldering Recommendations

Attention: For all of our array sensors we give no guarantee on the calibration and its performance if the pins are shortened by the customer. **Additionally, we strongly recommend to not solder the sensor with its back plate directly to a PCB.** This will cause different thermal conductivity compared to air and the measurement results could get worse. **Use a minimum gap between PCB and backplate of 2 mm or more.** The glass of the pins to the back plate can get damage by applying high temperatures (during soldering), which will lead into a lower temperature reading what cannot be repaired afterwards.




Figure 1: Soldering height

Manual Iron Soldering and Automatic Point-to-Point Iron Soldering

Manual Iron Soldering and Automatic Point-to-Point Iron Soldering methods are allowed for TO packages. It is recommended for through hole applications to shield the package body from soldering heat by PCB or similar.

The soldering iron temperature should be set as low as possible (maximum 350 °C) and should not exceed recommended soldering time (maximum 3 seconds). The minimum distance between the housing body and the liquid solder should be at least 1.5 mm for 350 °C. Reflow soldering is not recommended.

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 5 of 33

3 Principal Schematic for HTPA120x84d




Figure 2: Schematic for HTPA120x84d

* EE_Enable : The slave select is used to switch communication between sensor and EEPROM.

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 6 of 33

4 Pin Assignment – Bottom View




Figure 3: pin-allocation

Pin	Symbol	Description
1	MISO	Digital I/O, Serial data out of sensor
2	MOSI	Digital I/O, Serial data in of sensor
3	SCLK	Digital I/O, Serial clock
4	VDD	Positive supply voltage
5	VSS	Negative supply voltage / Ground (0V) (connected to housing)
6	$\overline{\text{EE_Enable}}$	Digital I/O, Sensor/EEPROM select



Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 7 of 33

5 Optical Orientation



Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 8 of 33



6 Order Code Example




Figure 4: Exemplary order code

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 9 of 33

7 Application note

This Application Note is giving a short recommendation for the connection of the HTPA120x84d to achieve the best performance. Adding 100 nF and 47 μ F are improving the stability of the supply voltage.




Figure 5: Recommended circuit for operation

The Sensor can be powered directly via 3.35 V if the supply voltage is stable enough, this has to be measured before and tested with the sensor. It is important to not insert any inductor or otherwise the noise will increase.

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 10 of 33

8 Serial Order of Frame

The sensor is divided into two parts (top and bottom half) which are again separated into 6 blocks. The readout order is shown below for the different blocks.

Block 0 (top)
Block 1 (top)
Block 2 (top)
Block 3 (top)
Block 4 (top)
Block 5 (top)
Block 5 (bottom)
Block 4 (bottom)
Block 3 (bottom)
Block 2 (bottom)
Block 1 (bottom)
Block 0 (bottom)

Figure 6: Division of blocks

Whenever a conversion is started the block x of the top and bottom half are measured at the same time. Each block consists of 840 Pixel that are sampled fully parallel. The readout order on the bottom half is mirrored compared to the top half so that the central lines are always read last.




Figure 7: 120x84d readout order for active pixel

The electrical offsets are sampled according to the top and bottom half. The matching rows for the corresponding electrical offsets and active Pixel are marked with the same color. The conversion of the electrical offsets is started by setting the BLIND bit during the start command.



Figure 8: 120x84d readout order for electrical offset

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 11 of 33



9 Characteristics

9.1 Common Specifications

Technology	n-poly/p-poly Si
Thermal pixel time constant	<5 ms
Digital Interface	SPI
Analog Output	No
selectable Clock	6 to 16 MHz
EEPROM size	512 kBit


Pitch	60 μm
Absorber size	52 μm
Max. Framerate	50 Hz

(complete frame with maximum SPI and sensor clock speed and reduced ADC resolution)
10080 sensitive elements

9.2 Filter characteristics

Available optical filter elements: CaF₂, BaF₂ and Sapphire

Typical filter transmissions by 1 mm thickness:



Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 12 of 33



10 Electric Specifications

Table 1: Absolute Maximum Ratings

Parameter	Symbol	Condition	MIN.	TYP.	MAX.	Unit
Supply Voltage	VDD		-0.3		3.6	V
Voltage at All inputs and outputs	VIO		-0.3		VDD+0.3	V
Storage Temperature	TSTG		-40		85	Deg. C

Table 2: Operating Conditions

Parameter	Symbol	Condition	MIN.	TYP.	MAX.	Unit
Supply Voltage	VDD		3.3	3.35	3.6	V
Supply Current (sensor running)	IDD		TBD	TBD	TBD	mA
Supply Current (sensor in idle state)	IDD		TBD	TBD	TBD	mA
Standby Current (sensor in sleep state)	ISBY		TBD	TBD	TBD	μA
Operation Temperature	TA		-20		85	Deg. C
ESD-Protection		Human body model	2.0			kV
		100pF + 1k50hm				

Table 3: Electrical Characteristics

Parameter	Symbol	Condition	MIN.	TYP.	MAX.	Unit
Digital Input						
Internal Clock frequency	FCLK		6	10	16	MHz
Internal I ² C Pull up	RPU		1	100	100	kOhm

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 13 of 33



Bias current	IBIAS		1	3	13	μA
BPA current	IBPA		0.2	1.5	4.0	μA
Input voltage high	VIH		0.7xVDD			V
Input voltage low	VIL				0.3xVDD	V
PTAT						
Temperature range			TBD		TBD	Deg. C
PTAT gradient			352	377	400	K/V

Table 4: Preamplifier / ADC

Parameter	Symbol	Condition	MIN.	TYP.	MAX.	Unit
Chopper frequency	FCHP			40		kHz
Preamplifier Noise	NPA	at 20 kHz		72		nV/Hz ^{1/2}
Frame rate (Full Array)	FR1		6	9	15	Hz
Frame rate (Sixth part Array)	FR4		36	54	90	Hz
ADC pos. Reference	VREFP	REF_CAL 00		1.57		V
		REF_CAL 01		1.47		
		REF_CAL 10		1.37		
		REF_CAL 11		1.27		
ADC neg. Reference	VREFN	REF_CAL 00		0.78		V
		REF_CAL 01		0.88		
		REF_CAL 10		0.98		
		REF_CAL 11		1.08		
ADC resolution	ADCLS B	at 16 Bit	5.8		24.1	μV

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 14 of 33



11 SPI Timings HTPA120x84d




Figure 9: SPI Timings HTPA120x84d

Table 5: SPI Timings

Parameter	Symbol	MIN.	TYP.	MAX.	Unit
SPI clock frequency	FCLK		10	13	MHz
low pulse duration	T _{CLK,lo}	30			ns
high pulse duration	T _{CLK,hi}	40			ns
data set up time	T _{SU,data}	30			ns
data hold time	T _{hd,data}	10			ns
start setup time	T _{SU,start}	50			ns
stop setup time	T _{SU,stop}	50			ns
Time between STOP/ START	T _{buf}	200			ns
Time startup (after Power-on Reset)	T _{startup}			100	μs
Time wakeup (after sending WAKEUP)	T _{wakeup}			80	μs

12 SPI Communication

The chip uses the 8-bit command for accessing configuration and sensor data.

The EE_Enable pin is utilized to switch the communication between sensor and internal non-volatile memory. Due to the need to toggle the EE_Enable pin the sensor with integrated EEPROM/FLASH requires a separate SPI interface. No other parts should use the same SPI lines in order to make sure that the parts can be selected correctly during communication.”

12.1 Write Command

In case of a write access to an internal register the command is followed by the data byte.




Figure 10: Write command

12.2 Read Command

To read data from the chip first the read command must be sent. The command initiates the read sequence and the first bit of read bytes will be set on MISO with falling edge of SCLK after last command bit. There can be as many byte reads as required.




Figure 11: Read command

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 16 of 33



12.3 Sensor Commands

The sensor has several registers that can be written and read, they are listed below.

Table 6: Configuration register (write only)

Addr / CMD	0x01							
Status Reg	7	6	5	4	3	2	1	0
Name	RFU	BLOCK			START	VDD_MEAS	BLIND	WAKEUP
Default	0	0	0	0	0	0	0	0

The WAKEUP bit is used to switch on / off the chip and must be set prior all other operations. After the START bit is set the chip starts a conversion of the array or blind elements and enters the idle state (not sleep!) when finished. The BLOCK selects one of the four multiplexed array blocks.

If the BLIND bit is set the electrical offsets are sampled instead of the active pixel and the setting of the BLOCK is ignored.

If VDD_MEAS bit is set the VDD voltage is measured instead of the PTAT value.

RFU means reserved for future use and can be subject to change.

Table 7: Status Register (read only)

Addr / CMD	0x02							
Status Reg	7	6	5	4	3	2	1	0
Name	RFU	BLOCK			RFU	VDD_MEAS	BLIND	EOC
Default	0	0	0	0	0	0	0	0

If the EOC flag is set a previous started conversion has been finished.

Table 8: Trim Register 1 (write only)

Addr / CMD	0x03							
Trim Reg 1	7	6	5	4	3	2	1	0
Name	RFU		REF_CAL			MBIT TRIM		

REF_CAL: selectable amplification

MBIT_TRIM: $m = 4$ to $12 \Rightarrow (m+4)$ bit as ADC resolution

Table 9: Trim Register 2 (write only)

Addr / CMD	0x04							
Trim Reg 2	7	6	5	4	3	2	1	0
Name	RFU				BIAS TRIM TOP			

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 17 of 33



BIAS_TRIM_TOP: 0 to 31 \Rightarrow 1 μ A to 13 μ A

This setting is used to adjust the bias current of the ADC. A faster clock frequency requires a higher bias current setting.

Table 10: Trim Register 3 (write only)

Addr / CMD	0x05							
Trim Reg 3	7	6	5	4	3	2	1	0
Name	RFU				BIAS TRIM BOT			

BIAS_TRIM_BOT: 0 to 31 \Rightarrow 1 μ A to 13 μ A

This setting is used to adjust the bias current of the ADC. A faster clock frequency requires a higher bias current setting.

Table 11: Trim Register 4 (write only)

Addr / CMD	0x06							
Trim Reg 4	7	6	5	4	3	2	1	0
Name	RFU				CLK TRIM			

CLK_TRIM: 0 to 63 \Rightarrow 6MHz to 16MHz

NOTE: The measure time depends on the clock frequency settings. One sixth frame takes about:

$$t_{conv} \approx \frac{32 \cdot (2^{MBIT} + 100)}{F_{CLK}} \approx 14 \text{ ms @ } 10 \text{ MHz}$$

Table 12: Trim Register 5 (write only)

Addr / CMD	0x07							
Trim Reg 5	7	6	5	4	3	2	1	0
Name	RFU				BPA TRIM TOP			

BPA_TRIM_TOP: 0 to 31 \Rightarrow 0.2 μ A to 4.0 μ A

This setting is used to adjust the common mode current of the preamplifier.

Table 13: Trim Register 6 (write only)

Addr / CMD	0x08							
Trim Reg 6	7	6	5	4	3	2	1	0
Name	RFU				BPA TRIM BOT			

BPA_TRIM_BOT: 0 to 31 \Rightarrow 0.2 μ A to 4.0 μ A

This setting is used to adjust the common mode current of the preamplifier.

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 18 of 33



Table 14: Read Data 1 Command (Top Half of Array)

CMD	0x0A							
Read Data	7	6	5	4	3	2	1	0
1. Byte / 2. Byte	PTAT 1 MSB / LSB or Vdd 1 MSB / LSB							
3. Byte / 4. Byte	Pixel (0+BLOCK*840) MSB / LSB							
5. Byte / 6. Byte	Pixel (1+BLOCK*840) MSB / LSB							
...	...							
1681. Byte / 1682. Byte	Pixel (839+BLOCK*840) MSB / LSB							

Table 15: Read Data 2 Command (Bottom Half of Array)

CMD	0x0B							
Read Data	7	6	5	4	3	2	1	0
1. Byte / 2. Byte	PTAT 2 MSB / LSB or Vdd 2 MSB / LSB							
3. Byte / 4. Byte	Pixel (9960-BLOCK*840) MSB / LSB							
5. Byte / 6. Byte	Pixel (9961-BLOCK*840) MSB / LSB							
...	...							
241. Byte / 242. Byte	Pixel (10079-BLOCK*840) MSB / LSB							
243. Byte / 244. Byte	Pixel (9840-BLOCK*840) MSB / LSB							
245. Byte / 246. Byte	Pixel (9841-BLOCK*840) MSB / LSB							
...	...							
481. Byte / 482. Byte	Pixel (9959-BLOCK*840) MSB / LSB							
483. Byte / 484. Byte	Pixel (9720-BLOCK*840) MSB / LSB							
...	...							
1681. Byte / 1682. Byte	Pixel (9359-BLOCK*840) MSB / LSB							

The complete sensor data must be read at once. If the communication fails somewhere in between, all successive data will be corrupted. The readout can be stopped anywhere. A new initialized readout proceeds at this stopped byte, but the index is reset when a new conversion has been started.

If the VDD_MEAS bit (Bit 2 in Config 0x01) is set then the Vdd is sampled instead of the PTAT.

If the bit for the electrical offsets (Bit 1 in Config 0x01) is set the electrical offsets are sampled and can be read similar to the active pixel:

Table 16: Read Data electrical offsets (Top Half of Array)

CMD	0x0A							
Read Data	7	6	5	4	3	2	1	0
1. Byte / 2. Byte	PTAT 1 MSB / LSB or Vdd 1 MSB / LSB							
3. Byte / 4. Byte	electrical offset (0) MSB / LSB							
5. Byte / 6. Byte	electrical offset (1) MSB / LSB							
...	...							
1681. Byte / 1682. Byte	electrical offset (839) MSB / LSB							

Table 17: Read Data electrical offsets (Bottom Half of Array)

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 19 of 33



Read Data electrical offsets (Bottom Half of Array)

Addr / CMD	0x0B							
Read Data	7	6	5	4	3	2	1	0
1. Byte / 2. Byte	PTAT 2 MSB / LSB or VDD 2 MSB / LSB							
3. Byte / 4. Byte	electrical offset (1560) MSB / LSB							
5. Byte / 6. Byte	electrical offset (1561) MSB / LSB							
...	...							
241. Byte / 242. Byte	electrical offset (1679) MSB / LSB							
243. Byte / 244. Byte	electrical offset (1440) MSB / LSB							
...	...							
1681. Byte / 1682. Byte	electrical offset (959) MSB / LSB							

The complete sensor data must be read at once. If the communication fails somewhere in between, all successive data will be corrupted. The readout can be stopped anywhere. A new initialized readout proceeds at this stopped byte, but the index is reset when a new conversion has been started.

12.4 EEPROM communication

The built-in EEPROM (25AA512 from Microchip) consists of 32 blocks of 1K x 8-bit. The chip select of the EEPROM is set to 0. For further information, please see the corresponding datasheet directly from Microchip.

www.microchip.com

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 20 of 33



12.5 SPI Example Sequences – Init and Read Thermopile Array

CONFIG_REG	WAKEUP
0x01	0x01

TRIM_REG1	MBIT_TRIM
0x03	0x0C

TRIM_REG2	BIAS_TRIML
0x04	0x0C

TRIM_REG3	BIAS_TRIMR
0x05	0x0C

TRIM_REG4	CLK_TRIM
0x06	0x14

TRIM_REG5	BPA_TRIML
0x07	0x0C

TRIM_REG6	BPA_TRIMR
0x08	0x0C

CONFIG_REG	START WAKEUP
0x01	0x09

STATUS_REG	STATUS
0x02	??

WAIT 30ms

STATUS_REG	STATUS
0x02	??

READ_DATA 1	PTAT1 MSB	PTAT1 LSB	P0,0 MSB	P0,0 LSB	...	Px,y MSB	Px,y LSB
0x0A	??	??	??	??	...	??	??

READ_DATA 2	PTAT2 MSB	PTAT2 LSB	P0,0 MSB	P0,0 LSB	...	Px,y MSB	Px,y LSB
0x0B	??	??	??	??	...	??	??

CONFIG_REG	SLEEP
0x01	0x00

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 21 of 33



13 Temperature calculation

The object and ambient temperature can be calculated from the sensor output and the stored calibration data. The table below is showing an overview of the EEPROM.

120x84d	0x00	0x01	0x02	0x03	0x04	0x05	0x06	0x07	0x08	0x09	0x0A	0x0B	0x0C	0x0D	0x0E	0x0F
0x0000	PixCmin (float)			PixCmax (float)			gradScale		TN as 16 bit unsigned			epsilon				
0x0010									MBIT(calib)		BIAS(calib)		CLK(calib)		BPA(calib)	
0x0020	Arraytype						VDDTH1		VDDTH2							
0x0030				PTAT-gradient (float)			PTAT-offset (float)			PTAT (Th1)		PTAT (Th2)				
0x0040													VddScGrad		VddScOff	
0x0050				GlobalOff			GlobalGain									
0x0060	MBIT(user)	BIAS(user)	CLK(user)	BPA(user)												
0x0070				DeviceID											NrOfDefPix	
0x0080	DeadPixAdr as 16 bit unsigned values															
...																
0x00D0	DeadPixMask															
0x00E0																
0x00F0																
0x0100	free to use															
0x0110																
...																
0x20E0	VddCompGrad stored as 16 bit sigend values															
...																
0x2DF0																
0x2E00	VddCompOff stored as 16 bit sigend values															
...																
0x3B10																
0x3B20	ThGrad _i stored as 8 bit signed values															
...																
0x6270																
0x6280	ThOffset _i stored as 16 bit signed values															
...																
0xB130																
0xB140	P _i stored as 16 bit unsigned values															
...																
0xFFFF																

Figure 12: EEPROM overview 120x84d

All values are stored as unsigned 8 bit values unless they are specified otherwise. The little endian format is used for larger values. Grey marked areas are used during calibration or for future use and are Heimann Sensor reserved.

MBIT(calib), BIAS(calib), CLK(calib), and BPA(calib) are the settings for the registers that have been used during calibration. We recommend the usage of calibration settings of MBIT (stored in 0x1A), BIAS (0x1B), CLK (0x1C) and BPA (0x1D).

MBIT(user), BIAS(user), CLK(user) and BPA(user) are free to be set by the user.

The temperature calculation is only valid if the same settings are used that have been set during calibration!

TN is the tablenumber and has to match the given tablenumber in the sample code.

GlobalOff is stored as an 8-bit signed value, GlobalGain and VddCalib are both stored as 16 bit unsigned.

VDDTH1 and VDDTH2 is the used supply voltage during calibration measured by the sensor itself and stored in Digits.

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 22 of 33



The corresponding order of $ThGrad_{ij}$, $ThOffset_{ij}$ and P_{ij} to the Pixel number is given by the following overview:

ThGrad _{0,0} → Pixel 0	ThGrad _{0,1} → Pixel 1	...	ThGrad _{0,119} → Pixel 119
ThGrad _{1,0} → Pixel 120	ThGrad _{1,1} → Pixel 121	...	ThGrad _{1,119} → Pixel 239
...			
ThGrad _{41,0} → Pixel 3240	ThGrad _{41,1} → Pixel 3241	...	ThGrad _{41,119} → Pixel 3359
ThGrad _{42,0} → Pixel 9960	ThGrad _{42,1} → Pixel 9961	...	ThGrad _{42,119} → Pixel 10079
ThGrad _{43,0} → Pixel 9840	ThGrad _{43,1} → Pixel 9841	...	ThGrad _{43,119} → Pixel 9959
...			
ThGrad _{83,0} → Pixel 3360	ThGrad _{83,1} → Pixel 3361	...	ThGrad _{83,119} → Pixel 3479

Figure 13: Readout order 120x84d

The order of $VddCompGrad_{ij}$ and $VddCompOff_{ij}$ is similar to the electrical Offsets and have to be used block by block.

VDDCompGrad _{0,0} → Pixel 0	VDDCompGrad _{0,1} → Pixel 1	...	VDDCompGrad _{0,119} → Pixel 119	top half
VDDCompGrad _{1,0} → Pixel 120	VDDCompGrad _{1,1} → Pixel 121	...	VDDCompGrad _{1,119} → Pixel 239	
...				
VDDCompGrad _{6,0} → Pixel 720	VDDCompGrad _{6,1} → Pixel 721	...	VDDCompGrad _{6,119} → Pixel 839	
VDDCompGrad _{8,0} → Pixel 840	VDDCompGrad _{8,1} → Pixel 841	...	VDDCompGrad _{8,119} → Pixel 959	
...				
VDDCompGrad _{6,0} → Pixel 4920	VDDCompGrad _{6,1} → Pixel 4921	...	VDDCompGrad _{6,119} → Pixel 5039	
VDDCompGrad _{7,0} → Pixel 9960	VDDCompGrad _{7,1} → Pixel 9961	...	VDDCompGrad _{7,119} → Pixel 10079	
VDDCompGrad _{8,0} → Pixel 9840	VDDCompGrad _{8,1} → Pixel 9841	...	VDDCompGrad _{8,119} → Pixel 9959	
...				
VDDCompGrad _{13,0} → Pixel 9240	VDDCompGrad _{13,1} → Pixel 9241	...	VDDCompGrad _{13,119} → Pixel 9359	bottom half
VDDCompGrad _{9,0} → Pixel 9120	VDDCompGrad _{9,1} → Pixel 9121	...	VDDCompGrad _{9,119} → Pixel 9239	
...				
VDDCompGrad _{13,0} → Pixel 5040	VDDCompGrad _{13,1} → Pixel 5041	...	VDDCompGrad _{13,119} → Pixel 5159	

Figure 14: Readout order of VDDCompGrad 120x84d

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 23 of 33



13.1 Ambient Temperature

The ambient temperature (T_a) is calculated from the average measured PTAT value, the PTAT_{gradient} and the PTAT_{offset}. It is recommended to use a stack buffer for the PTAT values in order to get a more stable ambient temperature result.

$$T_a = PTAT_{av} \cdot PTAT_{gradient} + PTAT_{offset} \quad (\text{Value is given back in dK})$$

where:

$PTAT_{gradient}$ is the gradient of the PTAT stored in the EEPROM as a float value

$PTAT_{offset}$ is the offset of the PTAT stored in the EEPROM as a float value

$PTAT_{av} = \frac{\sum_{i=0}^{11} PTAT_{ij}}{12}$ is the average measured PTAT value

13.2 Thermal Offset

The thermal offset of the sensor needs to be subtracted for each pixel to compensate for any thermal drifts.

$$V_{ij_comp} = V_{ij} - \frac{ThGrad_{ij} \cdot PTAT_{av}}{2^{gradScale}} - ThOffset_{ij}$$

where:

ij represents the row (i) and column (j) of the pixel

V_{ij_comp} is the thermal offset compensated voltage

V_{ij} is the raw pixel data (digital), readout from the RAM

$ThGrad_{ij}$ is the thermal gradient, stored in the EEPROM from 0x3B20 to 0x6270

$ThOffset_{ij}$ is the thermal offset, stored in the EEPROM from 0x6280 to 0xB130

$gradScale$ is the scaling coefficient for the thermal gradient stored in the EEPROM

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 24 of 33



13.3 Electrical Offset

The electrical offset is used to compensate changes in the supply voltage. This compensation is only a subtraction so it can be done before or after the thermal offset compensation (here done afterwards). It is recommended to use an electrical offset stack in order to get a more stable electrical offset result and a more stable temperature result at the end. The electrical offsets should be sampled every 8th to 10th frame.

The compensation for the top half is done by using the following formula:

$$V_{ij_Comp}^* = V_{ij_Comp} - elOffset[(j + i \cdot 120)\%840]$$

and the bottom half analogue with this formula:

$$V_{ij_Comp}^* = V_{ij_Comp} - elOffset[(j + i \cdot 120)\%840 + 840]$$

where:

ij represents the row (i) and column (j) of the pixel and electrical offset

$V_{ij_Comp}^*$ is the thermal and electrical offset compensated voltage

V_{ij_Comp} is the thermal offset compensated voltage

$elOffset_{ij}$ is the electrical offset belonging to Pixel ij

$i\%: 840$ is the rest of the integer division of i by 840 (e.g. $842\%840=2$)

13.4 Vdd Compensation

A supply voltage compensation called VddComp is used to take care of supply voltage changes. In order to use this compensation the supply voltage of the sensor (Vdd) has to be measured by the sensor from time to time by setting the configuration register and the average of Vdd 1 and Vdd 2 is resulting in Vdd (similar like $PTAT_{av}$). It is recommended to use a VDD stack buffer in order to get a more stable VDD value. The stack should be similar to the PTAT stack.

The compensation for the top half is done by using the following formula:

$$VDD_{av} = \frac{\sum_{i=0}^{11} VDD_i}{12}$$

$$V_{ijVDDComp} = V_{ijComp}^* - \left(\frac{VddCompGrad[(j + i \cdot 120)\%840] \cdot PTAT_{av}}{2^{VDDScGrad}} + VddCompOff[(j + i \cdot 120)\%840] \right) \cdot 2^{VDDScOff}$$

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 25 of 33



$$\cdot \left(VDD_{av} - VDD_{TH1} - \left(\frac{VDD_{TH2} - VDD_{TH1}}{PTAT_{TH2} - PTAT_{TH1}} \right) \cdot (PTAT_{av} - PTAT_{TH1}) \right)$$

and the bottom half analogue with this formula:

$$V_{ij_VDDComp} = V_{ij_Comp}^*$$

$$- \frac{\left(\frac{VddCompGrad[(j + i \cdot 120)\%840 + 840] \cdot PTAT_{av} + VddCompOff[(j + i \cdot 120)\%840 + 840]}{2^{VDDScGrad}} \right)}{2^{VDDScOff}} \cdot \left(VDD_{av} - VDD_{TH1} - \left(\frac{VDD_{TH2} - VDD_{TH1}}{PTAT_{TH2} - PTAT_{TH1}} \right) \cdot (PTAT_{av} - PTAT_{TH1}) \right)$$

where:

ij represents the row (i) and column (j) of the pixel

$V_{ij_VDDComp}$ is the Vdd compensated voltage

$V_{ij_Comp}^*$ is the thermal and electrical offset compensated voltage

$VddComGrad[ij]$ is the VddComp gradient belonging to Pixel ij

$VddComOff[ij]$ is the VddComp offset belonging to Pixel ij

$i\%840$ is the rest of the integer division of i by 840 (e.g. $842\%840=2$)

VDD_{av} is the average measured supply voltage of the sensor in Digits

$VddScGrad$ is a scaling coefficient and stored in the EEPROM 0x4E

$VddScOff$ is a scaling coefficient and stored in the EEPROM 0x4F

VDD_{TH1} is the supply voltage during calibration 1 stored in the EEPROM 0x26, 0x27

VDD_{TH2} is the supply voltage during calibration 2 stored in the EEPROM 0x28, 0x29

$PTAT_{TH1}$ is the PTAT value of calibration 1 stored in the EEPROM 0x3C, 0x3D

$PTAT_{TH2}$ is the PTAT value of calibration 2 stored in the EEPROM 0x3E, 0x3F

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 26 of 33



13.5 Object Temperature

The calculation of the object temperature is done by using a look-up table and doing a bi-linear interpolation, the matching table is given by the tablenumber (TN). The table is supplied in a separate file named "Table.c". If you do not have the file, please ask Heimann Sensor for support.

The sensitivity coefficients ($PixC_{ij}$) are calculated in the following way:

$$PixC_{ij} = \left(\frac{P_{ij} \cdot (PixC_{max} - PixC_{min})}{65535} + PixC_{min} \right) \cdot \frac{\epsilon}{100} \cdot \frac{GlobalGain}{10000}$$

where:

$PixC_{ij}$ is the sensitivity coefficient for each pixel

P_{ij} is the stored sensitivity coefficient scaled to 16 bit

$PixC_{min}$ is the minimum sensitivity coefficient, used for scaling

$PixC_{max}$ is the maximum sensitivity coefficient, used for scaling

ϵ is the emissivity factor

$GlobalGain$ is a factor for fine tuning of the sensitivity for all Pixel

Leading to a compensation of the pixel voltage

$$V_{if_PixC} = \frac{V_{ij_VDDComp} \cdot PCSCALEVAL}{PixC_{ij}}$$

where:

V_{if_PixC} is the sensitivity compensated IR voltage

$PCSCALEVAL$ is a defined scaling coefficient, typically set to $1 \cdot 10^8$

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 27 of 33



14 Example calculation

Example values:

$$PTAT_{av} = \frac{\sum_{i=0}^{11} PTAT_i}{12} = 38152 \text{Digits}$$

$$PTAT_{gradient} = 0.0211 \text{ dK/Digit}$$

$$PTAT_{offset} = 2195.0 \text{ dK}$$

$$V_{00} = 34435 \text{ Digits}$$

$$elOffset[0] = 34240$$

$$gradScale = 17$$

$$THGrad_{00} = 87 \rightarrow \text{signcheck } 87$$

$$THOffset_{00} = 65506 \rightarrow \text{signcheck } - 30$$

$$VDD_{av} = 35000$$

$$VDD_{TH1} = 33942$$

$$VDD_{TH2} = 36942$$

$$PTAT_{TH1} = 30000$$

$$PTAT_{TH2} = 42000$$

$$VddCompGrad[0] = 10356 \rightarrow \text{signcheck } 10356$$

$$VddCompOff[0] = 51390 \rightarrow \text{signcheck } - 14146$$

$$VddScGrad = 16$$

$$VddScOff = 23$$

$$PixC_{00} = 1.087 \cdot 10^8$$

$$PCSCALEVAL = 1 \cdot 10^8$$

Calculation of ambient temperature:

$$Ta = PTAT_{av} \cdot PTAT_{gradient} + PTAT_{offset} = 38152 \cdot 0.0211 + 2195.0 \text{ dK} = 3000 \text{ dK}$$

Compensation of thermal offset:

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 28 of 33



$$V_{00_Comp} = V_{00} - \frac{ThGrad_{00} \cdot PTAT_{av}}{2^{gradScale}} - ThOffset_{00} = 34435 - \frac{87 \cdot 38152}{2^{17}} - (-30)$$

$$= 34439$$

Compensation of electrical offset:

$$V_{00_Comp}^* = V_{00_Comp} - elOffset[0] = 34439 - 34240 = 199$$

Compensation of supply voltage:

$$V_{ij_VDDComp} = V_{ij_Comp}^* - \frac{\left(\frac{VddCompGrad[0] \cdot PTAT_{av}}{2^{VddScGrad}} + VDDCompOff[0] \right)}{2^{VddScGrad}}$$

$$\cdot \left(VDD_{av} - VDD_{TH1} - \left(\frac{VDD_{TH2} - VDD_{TH1}}{PTAT_{TH2} - PTAT_{TH1}} \right) \cdot (PTAT_{av} - PTAT_{TH1}) \right)$$

$$= 199 - \frac{\left(\frac{10356 \cdot 38152}{2^{16}} - 14146 \right) \cdot (35000 - 33942 - 2038)}{2^{23}} = 199 - (1) = 198$$

Table 18: Example look-up table

TA[dK]/dig	2882	3032	3182	3332
-64	1494	2128	2491	2775
-32	2466	2692	2898	3091
0	2882	3032	3182	3332
32	3170	3285	3406	3530
64	3396	3491	3592	3699
96	3584	3665	3754	3848
128	3746	3818	3897	3981
160	3890	3954	4025	4102
192	4019	4078	4143	4214
224	4137	4191	4251	4317
256	4246	4296	4351	4413
288	4347	4393	4445	4503
320	4441	4485	4534	4588

$$V_{00_PixC} = \frac{198 \cdot 1 \cdot 10^8}{1.087 \cdot 10^8} = 182$$

Ta was calculated before to 3000 dK.

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 29 of 33



The matching region in the look-up table is already marked yellow, the bi-linear interpolation is leading to an object temperature of $4026 \text{ dK} = 129.4 \text{ }^\circ\text{C}$.

A global Offset (GlobalOff) is used for fine tuning of the measured object temperature and has to be added to the object temperature. This value is stored in the EEPROM.

14.1 Pixel Masking

A maximum of 48 defect Pixels is allowed on the complete array; this means that at least 99.5 % of the Pixels are working correctly. The amount of defect Pixels is given in the EEPROM at address $0x007F$ and is named *NrOfDefPix*. *DeadPixAdr* is the address of the defect Pixels and *DeadPixMask* determines the neighbours that should be used for masking the pixel. A simple averaging of all selected nearest neighbours is done to overwrite the temperature value of these Pixel. Only the amount of pixels “*NrOfDefPix*” is stored in *DeadPixAdr*. These values are stored as 16 bit unsigned values. For example: If only one pixel has to be masked, then the other values of *DeadPixAdr* are set to 0.

The order of the top and bottom half is the same as the readout order. The neighbours to use is given in a binary format and the order is shown in the overview below in decimal and binary values for the top and bottom half.

$$\text{adaptedAdr}[i] = 10080 + 5040 - \text{DeadPixAdr}[i] + k[i] \cdot 2 - 120$$

where:

adaptedAdr[*i*] is the adapted dead pixel address

k[*i*] is the column of the corresponding pixel (for pixel number 9959 this would be 119)

$$\text{adaptedAdr}[i] = 10080 + 5040 - 9959 + 119 \cdot 2 - 120 = 5279$$

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 30 of 33



top half

128	1	2
64	DeadPix	4
32	16	8

0b1000 0000	0b0000 0001	0b0000 0010
0b0100 0000	DeadPix	0b0000 0100
0b0010 0000	0b0001 0000	0b0000 1000

bottom half

32	16	8
64	DeadPix	4
128	1	2

0b0010 0000	0b0001 0000	0b0000 1000
0b0100 0000	DeadPix	0b0000 0100
0b1000 0000	0b0000 0001	0b0000 0010

Example values for the masking:

$NrOfDefPix = 0x03$

$DeadPixAdr[0] = 0x002D \rightarrow Pixel\ 45$

$DeadPixAdr[1] = 0x031F \rightarrow Pixel\ 799$

$DeadPixAdr[2] = 0x1429 \rightarrow Pixel\ 5161$ (read – out pixel) actual pixel number is 9841

$DeadPixMask[0] = 0x7C \rightarrow 0b01111100$ (top)

$DeadPixMask[1] = 0x8F \rightarrow 0b10001111$ (top)

$DeadPixMask[2] = 0xFE \rightarrow 0b11111110$ (bot)

According to the sample values 3 Pixels are defect and need to be interpolated. 2 Pixels are on the top and 1 Pixel on the bottom half. Assuming that the neighbouring Pixels are having the temperature data stated below and the green marked cells are used for averaging (according to DeadPixMask) then the interpolated temperature will be the following:

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 31 of 33



All values are given in dK

3007	Pixel 45	3008
3008	3011	3009

Pixel 44	Pixel 45	Pixel 46
Pixel 163	Pixel 164	Pixel 165

3010	3012	3005
3007	Pixel 799	3008
3008	3011	3009

Pixel 678	Pixel 679	Pixel 680
Pixel 798	Pixel 799	Pixel 800
Pixel 918	Pixel 919	Pixel 920

3010	3012	3005
3007	Pixel 9841	3008
3008	3011	3009

Pixel 9720	Pixel 9721	Pixel 9722
Pixel 9840	Pixel 9841	Pixel 9842
Pixel 9960	Pixel 9961	Pixel 9962

If a pixel is masked, the adjacent neighbours must have not more than 4 dead pixels in serial order, if you check them clockwise (or the other way around):

OK		
0	1	0
0	0	1
1	0	0

OK		
0	1	0
0	0	1
0	0	1

NOK		
0	1	1
0	0	1
0	0	0

Beam Profiler HTPA120x84d

Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 32 of 33



14.2 Look-up Table

The matching look-up table has to be taken from the Table.c file. Here is just shown an exemplary data for one optics.

dig \ Tal[dK]	2782	2882	2982	3082	3182	3282	3382	6848	6877	6920	6974	7039	7114	7198	7292
-256				1159	1804	2115	2343	6912	6892	6936	6990	7055	7130	7214	7306
-192				2211	2407	2576	2727	6976	6908	6951	7006	7071	7146	7230	7322
-128				2835	2742	2872	2995	7040	6923	6966	7021	7086	7162	7246	7338
-64				3573	2985	3007	3208	7104	6939	6982	7036	7102	7177	7262	7354
0	2782	2882	2982	3082	3182	3282	3382	7168	6994	6997	7052	7117	7193	7277	7370
64	2993	3078	3166	3256	3347	3440	3534	7232	6989	7012	7067	7133	7209	7293	7386
128	3167	3243	3322	3405	3491	3579	3669	7296	6999	7042	7097	7163	7239	7324	7417
192	3316	3385	3459	3537	3619	3703	3790	7360	7014	7047	7112	7178	7254	7339	7432
256	3448	3512	3582	3656	3734	3816	3901	7424	7088	7130	7195	7261	7338	7424	7517
320	3565	3626	3693	3764	3840	3920	4003	7488	7208	7273	7339	7406	7483	7569	7662
384	3673	3731	3794	3864	3938	4016	4097	7552	7243	7298	7364	7431	7508	7594	7687
448	3771	3827	3889	3956	4029	4105	4186	7616	7297	7352	7418	7485	7562	7648	7741
512	3863	3916	3977	4043	4114	4189	4269	7680	7372	7427	7493	7560	7637	7723	7816
576	3948	4000	4059	4124	4194	4269	4348	7744	7448	7503	7569	7636	7713	7799	7892
640	4028	4079	4137	4200	4270	4344	4423	7808	7524	7579	7645	7712	7789	7875	7968
704	4104	4154	4210	4273	4342	4415	4494	7872	7600	7655	7721	7788	7865	7951	8044
768	4176	4224	4280	4342	4410	4484	4561	7936	7676	7731	7797	7864	7941	8027	8120
832	4247	4293	4346	4408	4478	4549	4626	8000	7756	7811	7877	7944	8021	8107	8199
896	4309	4356	4410	4471	4538	4611	4689	8064	7836	7891	7957	8024	8101	8187	8279
960	4371	4417	4471	4532	4599	4671	4748	8128	7916	7971	8037	8104	8181	8267	8359
1024	4431	4476	4530	4590	4657	4729	4806	8192	7996	8051	8117	8184	8261	8347	8439
1088	4488	4533	4586	4646	4713	4785	4862	8256	8076	8131	8197	8264	8341	8427	8519
1152	4543	4588	4641	4700	4767	4839	4916	8320	8156	8211	8277	8344	8421	8507	8599
1216	4597	4641	4693	4753	4819	4891	4968	8384	8236	8291	8357	8424	8501	8587	8679
1280	4648	4692	4744	4803	4869	4941	5018	8448	8316	8371	8437	8504	8581	8667	8759
1344	4698	4742	4793	4852	4918	4990	5068	8512	8384	8439	8505	8572	8649	8735	8827
1408	4746	4790	4841	4900	4966	5038	5115	8576	8452	8507	8573	8640	8717	8803	8895
1472	4793	4836	4888	4946	5012	5084	5162	8640	8520	8575	8641	8708	8785	8871	8963
1536	4839	4881	4933	4991	5057	5129	5207	8704	8588	8643	8709	8776	8853	8939	9031
1600	4883	4925	4977	5035	5101	5173	5251	8768	8656	8711	8777	8844	8921	9007	9100
1664	4926	4968	5019	5078	5144	5216	5294	8832	8724	8779	8845	8912	8989	9075	9167
1728	4968	5010	5061	5120	5185	5258	5336	8896	8792	8847	8913	8980	9057	9143	9235
1792	5009	5051	5102	5160	5223	5296	5374	8960	8848	8903	8969	9036	9113	9199	9291
1856	5049	5091	5142	5200	5266	5338	5417	9024	8904	8959	9025	9092	9169	9255	9347
1920	5088	5130	5180	5239	5305	5377	5456	9088	8964	9019	9085	9152	9229	9315	9407
1984	5126	5168	5218	5277	5343	5416	5494	9152	8996	9051	9117	9184	9261	9347	9439
2048	5164	5205	5256	5314	5380	5453	5532	9216	9028	9083	9149	9216	9293	9379	9471
2112	5202	5242	5292	5350	5417	5489	5569	9280	9060	9115	9181	9248	9325	9411	9503
2176	5238	5277	5328	5386	5453	5526	5605	9344	9092	9147	9213	9280	9357	9443	9535
2240	5271	5312	5363	5421	5488	5561	5640	9408	9124	9179	9245	9312	9389	9475	9567
2304	5305	5347	5397	5456	5522	5595	5674	9472	9156	9211	9277	9344	9421	9507	9600
2368	5338	5380	5431	5489	5556	5629	5708	9536	9188	9243	9309	9376	9453	9539	9632
2432	5372	5413	5464	5523	5589	5663	5742	9600	9220	9275	9341	9408	9485	9571	9664
2496	5405	5446	5496	5555	5622	5696	5775	9664	9252	9307	9373	9440	9517	9603	9696
2560	5437	5478	5528	5587	5654	5728	5808	9728	9284	9339	9405	9472	9549	9635	9728
2624	5468	5509	5559	5619	5685	5759	5840	9792	9316	9371	9437	9504	9581	9667	9760
2688	5498	5540	5589	5649	5716	5790	5871	9856	9348	9403	9469	9536	9613	9700	9792
2752	5529	5570	5621	5680	5747	5821	5902	9920	9380	9435	9501	9568	9645	9732	9824
2816	5559	5600	5651	5710	5777	5851	5932	9984	9412	9467	9533	9600	9677	9764	9856
2880	5588	5629	5680	5739	5806	5881	5962	10048	9444	9499	9565	9632	9709	9796	9888
2944	5617	5658	5709	5768	5836	5910	5992	10112	9476	9531	9597	9664	9741	9828	9920
3008	5646	5687	5737	4945	5894	5969	6051	10176	9508	9563	9629	9696	9773	9860	9952
3072	5674	5715	5765	5825	5893	5968	6049	10240	9540	9595	9661	9728	9805	9892	9984
3136	5701	5742	5793	5853	5920	5996	6078	10304	9572	9627	9693	9760	9837	9924	10016
3200	5729	5770	5820	5880	5948	6023	6105	10368	9604	9659	9725	9792	9869	9956	10048
3264	5756	5797	5847	5907	5975	6051	6133	10432	9636	9691	9757	9824	9901	9988	10080
3328	5782	5823	5874	5934	6002	6078	6160	10496	9668	9723	9789	9856	9933	10020	10112
3392	5808	5849	5900	5960	6028	6104	6187	10560	9699	9754	9820	9887	9964	10051	10143
3456	5834	5875	5926	5986	6054	6130	6213	10624	9730	9785	9851	9918	9995	10082	10174
3520	5859	5900	5951	6012	6080	6156	6239	10688	9762	9817	9883	9950	10027	10114	10206
3584	5885	5926	5977	6037	6105	6182	6265	10752	9794	9849	9915	9982	10059	10146	10238
3648	5910	5951	6002	6062	6130	6207	6290	10816	9826	9881	9947	10014	10091	10178	10270
3712	5934	5975	6026	6086	6155	6232	6315	10880	9858	9913	9979	10046	10123	10210	10302
3776	5958	5999	6050	6111	6180	6257	6340	10944	9890	9945	10011	10078	10155	10242	10334
3840	5982	6023	6074	6135	6204	6281	6365	11008	9922	9977	10043	10110	10187	10274	10366
3904	6006	6047	6098	6159	6228	6305	6389	11072	9954	10009	10075	10142	10219	10306	10398
3968	6029	6070	6121	6182	6251	6328	6413	11136	9986	10041	10107	10174	10251	10338	10430
4032	6052	6093	6145	6205	6275	6352	6437	11200	10018	10073	10139	10206	10283	10370	10462
4096	6075	6116	6167	6228	6298	6376	6460	11264	10050	10105	10171	10238	10315	10402	10494
4160	6097	6139	6190	6251	6321	6399	6484	11328	10082	10137	10203	10270	10347	10434	10526
4224	6120	6162	6213	6274	6344	6422	6507	11392	10114	10169	102				

Beam Profiler HTPA120x84d


Thermopile Array with Planar Filter

Rev 0: 2024-12- Lupp / Nägler

Page 33 of 33



15 Outer Dimension



HEIMANN
Maria-R
D-01109